


COLLEGAMENTI ELETTRICI

OVEN SWITCH	8			
0	72	144	216	288
4 - P2				
3 - P1				
1 - P1				
2 - P1				
5 - P3				



COMM. FORNO DREEFS

POSITION	0	1	ENERGY REGULATOR ①②③④			
S	0	S				
P ₂	0	4				
P ₁	0	1				

ENERGY REGULATOR ①②③④

