


OVEN SWITCH

0	30	60-240	270	300
4 - P2				
3 - P1				
1 - P1				
2 - P1				
5 - P3				



ENERGY REGULATOR ②④

POSITION	0	1	7	mat.
S	→ S			
P2	→ 4			
P1	→ 1			

DOUBLE ENERGY REGULATOR ①③

POSITION	0	1	12
S	→ S		
P2	→ 4		
P1	→ 2		
4	→ 4A		

