


OVEN SWITCH

0	72	144	216	288
4 - P2				
3 - P1				
1 - P1				
2 - P1				
5 - P3				



ENERGY REGULATOR 1 2 3 4

POSITION	0	1	2	3	4	7 max.
S	0	0	S			
P ₂	0	0	4			
P ₁	0	0	1			

