


OVEN SWITCH	8	72	144	216	288
4 - P2					
3 - P1					
1 - P1					
2 - P1					
5 - P3					



ENERGY REGULATOR ②④

POSITION	0	1	7	max.
S				
P2				
P1				

DOUBLE ENERGY REGULATOR ①③

POSITION	0	1	12
S			
P2			
P1			
4			

