

L

N

WIRING

OVEN SWITCH

| | 0 | | | |
|--------|---|--|--|--|
| 4 - P2 | | | | |
| 3 - P1 | | | | |
| 1 - P1 | | | | |
| 2 - P1 | | | | |
| 5 - P3 | | | | |

