


ELECTRIC DIAGRAM
DIAGRAMMA ELETTRICO



POSIZIONI	P1	P2	P3	P4	P5	P6	P7	P8
0								
1	■							⊕
2		■						⊖
3			■					⊖
4				■				⊖
5					■			⊖
6						■		⊖
7							■	⊖
8								⊖
9								⊕

OVEN SWITCH 1