













STEAM GENERATOR



POSITIONS	1	2	3	4	5	6	7	8	9	10	11	COOKING FUNCTIONS
0												
1	X				X	X	X					35.00°
2	X	X	X	X		X	X	X				72.00°
3	X	X	X		X		X	X	X			106.00°
4	X			X			X	X	X			144.00°
5	X	X		X			X	X	X			180.00°
6	X	X			X		X	X	X			216.00°
7	X			X	X		X	X	X			252.00°
8	X	X	X		X		X	X	X			288.00°
9	X			X			X	X	X			324.00°
10												
11												

STEAM START THERMOSTAT



SUPPLY BOX

