



ANC ROTARY SWITCH: A12616701

SWITCHING DIAGRAM

| POSITIONS | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | FUNCTIONS |
|-----------|---|---|---|---|---|---|---|---|---|---------------|
| 0 | | | | | | | | | | 0° ∠ |
| 1 | X | | | | | X | X | X | | 45.00° ∠ |
| 2 | X | X | X | | | X | X | X | | 90.00° ∠ |
| 3 | X | X | | X | | X | X | X | | 135.00° ∠ ECO |
| 4 | X | X | | | | X | X | X | | 180.00° ∠ * |
| 5 | X | | | | X | X | X | X | | 225.00° ∠ |
| 6 | X | | | X | X | X | X | X | | 270.00° ∠ |
| 7 | X | X | X | X | X | X | X | X | | 315.00° ∠ * |

A12579002

P00ZO300005188