



POSITIONS	CONTACTS (REAR VIEW)											COOKING FUNCTIONS
	1A	2A	3A	4A	5A	6A	7A	8A	9A	10A	11A	
0												0°
1	X					X	X	X	X	X	X	35.00°
2	X	X	X		X		X	X	X	X	X	72.00°
3	X	X			X		X		X	X	X	108.00°
4	X			X			X	X	X	X	X	144.00°
5	X	X		X			X	X	X	X	X	180.00°
6	X	X			X		X	X	X	X	X	215.00°
7	X			X	X		X	X	X	X	X	252.00°
8	X	X	X		X		X	X	X	X	X	288.00°
9	X		X	X		X	X	X	X	X	X	324.00°

ANC ROTARY SWITCH: A12342101