



**CONTACTS (REAR VIEW)**

1A	2A	3A	4A	5A	6A	7A	8A	9A	10A	11A
1				X						
2	X	X	X		X			X	X	X
3	X			X		X	X	X	X	
4			X			X	X	X	X	
5				X	X	X	X	X	X	
6	X			X	X	X	X	X	X	
7	X	X		X	X	X	X	X	X	
8			X	X		X	X	X	X	

**COOKING FUNCTIONS**

0										0°
1					X	X	X			40.00°
2	X	X	X		X	X	X			80.00°
3	X			X		X	X			120.00° ECO
4			X			X	X			150.00°
5				X	X	X	X			200.00°
6	X			X	X	X	X			240.00°
7	X	X		X	X	X	X			280.00°
8			X	X		X	X			320.00°

ANC ROTARY SWITCH: A12616801