



Diagram illustrating the electrical wiring for the washing machine, showing components like the Door safety interlock, Pressure switch, Cold water inlet valve, Drain pump, Heating elements, Adjustable thermostat, Pressure switch, Super rinse button, Rinse-hold button, No-spin button, and Motor.