



MAIN ELECTRONIC BOARD

Temperature probe(washing)

Door safety interlock

Programme selector

2-3

5-6

7

8

9

10

11

12

13

14

15

16

17

18

19

20

21

22

23

24

25

26

27

28

29

30

31

32

33

34

35

36

37

38

39

40

41

42

43

44

45

46

47

48

49

50

51

52

53