



Heating elements

Recirculation pump


Door safety interlock



Motor




132.12613/




132.12760/

Drain pump



Pressure switch



132.12752/

MAIN ELECTRONIC BOARD

EWM2000 EVO WM


Analogic pressure level



132.12801/

132.12671/

Anti-interference filter



132.12743/

USER INTERFACE BOARD

124.11050/

Earth

Junction box


124.34040/

Tub earth

Motor earth

Heating element earth

Programme selector



124.93313/

124.93311/

Prewash valve

Wash valve



132.12630/