

Recirculation pump

124.96170/

Motor

1 2 3 4 5 6 7 8 9 10

Analogic pressure level

124.96350/

Air chamber on tub

132.02001/

Pressure switch

AE-2

21 22 23 24

AE-1

12 13 14 15

31

Anti-interference filter

132.02012/

Earth

Junction box

124.11050/

124.96300/

ON-OFF button

37928574/


Pilot lamp

124.96290/

Tub earth

Motor earth

Heating element earth



Heating elements (washing)

Temperature Probe

Door locked lamp

37928541/


Drain pump

WIRES ORANGE

MAIN ELECTRONIC BOARD

WIRES ORANGE

132.02021/



Buzzer

124.93314/

USER INTERFACE BOARD

Programme selector

124.93313/

124.93311/

132.02031/

Prewash valve



Wash valve

