



Heating elements

Recirculation pump


Door safety interlock



Motor



Pressure switch




Analogic pressure level




Anti-interference filter




Earth



Junction box




Prewash valve  
Wash valve



Door locked lamp



Drain pump



MAIN ELECTRONIC BOARD

EWM2000 EVO WM

USER INTERFACE BOARD

Programme selector



132.12613/

132.12752/

132.12801/

132.12744/

124.11050/

124.34040/

132.12630/

132.12760/

37928593/

132.12672/

132.12808/

124.93311/