




Heating elements


Recirculation pump

Door safety interlock




132.12760/

Motor



132.12615/


Drain pump



MAIN ELECTRONIC BOARD

EWM2000 EVO WM

Pressure switch



132.12754/

Analogic pressure level



132.12801/

132.12672/


Anti-interference filter



132.12782/

132.12806/

Earth



124.11050/

Junction box

124.96302/


124.96290/

Tub earth

Motor earth



Heating element earth

Programme selector



132.12805/

USER INTERFACE BOARD



132.12630/

Prewash valve

Wash valve

