




Heating elements

Recirculation pump



Door safety interlock




132.12600/



132.12760/




Pressure switch



132.12750/

MAIN ELECTRONIC BOARD

EWM2000 EVO WM




Analogic pressure level



132.12801/

Anti-interference filter




132.12732/

Earth

124.11050/

Junction box


124.34040/



Motor earth

Heating element earth

USER INTERFACE BOARD



124.93313/

124.93311/

ON/OFF button


37928556/



Pilot lamp

Prewash valve

Wash valve



132.12630/