



Tub earth

132.24000/

Door safety interlock

Heating elements

Recirculation pump

132.24020/

Temperature probe

Acqua Control

Drain pump

132.24130/

EXTERNAL MOTOR CONTROL BOARD

Fan Motor

Temperature probe (umidity control)

132.12809/

Motor

MAIN ELECTRONIC BOARD

EWM3000 -WD-

132.24010/

Pressure switch

132.24140/

AE-1\*  
AE-2\*

132.12803/

Analogic pressure level

Heating elements (drying)

124.13964/

Thermostat

Overheat protection thermostat

132.24470/

Anti-interference filter

132.24461/

Earth

124.11050/

132.02150/

Junction box

Drying pipe earth

132.12812/

Controls support earth

Flow sensor

Wash valve

Prewash valve

Condensation valve

132.24320/

Programme selector

132.02791/

Temperature probe (drying)

132.24380/

132.12806/

USER INTERFACE BOARD

124.80380/

124.93313/