



Recirculation pump




132.12880/

Motor



1 2 3 4 5 6 7 8

Analogic pressure level




124.96350/


Air chamber on tub

132.02001/

Pressure switch




Anti-interference filter



Earth

124.11050/

Junction box



124.34040/

Motor earth

Heating element earth

ON-OFF button




37928556/

Pilot lamp



Tub earth

Heating elements (washing)




Temperature Probe

WIRES ORANGE


Drain pump

MAIN ELECTRONIC BOARD




WIRES ORANGE

132.02021/



USER INTERFACE BOARD


Programme selector



124.93314/

124.93313/

124.93311/




Wash valve BLACK

Prewash valve WHITE

Bleaching valve GREEN

WIRES BLUE



124.96420/