





Rinse Hold Button

Super Rinse button  
X2.1  
X2.2  
H2.1  
H2.2  
S4.1  
S4.2  
S4.3  
S4.4  
No Spin Button  
S4.1  
S4.2  
S4.3  
S4.4


W2.1  
W2.2  
F2.1  
F2.2  
R2.1  
R2.2  
J5.1  
J5.2  
J5.3  
J5.4  
J5.5

Timer & Electronic module

M7.2  
M7.3  
M7.4  
M7.5  
M7.6  
M7.7  
A2.1  
A2.2  
N6.1  
N6.2  
N6.3  
N6.4  
N6.5  
N6.6  
P5.1  
P5.2  
P5.3  
L2.1  
L2.2  
B4.1  
B4.2  
B4.4



Heating elements (washing)



Pressure switch

Pressure switch

Door safety interlock

ON-OFF button

