



Heating elements

Recirculation pump

Door safety interlock





132.12760/

132.12844/

132.12782/

Drain pump




132.12615/

MAIN ELECTRONIC BOARD

EWM2000 EVO WM

Pressure switch




Analogic pressure level



132.12801/

132.12692/

Anti-interference filter



132.12806/


Junction box

124.11050/

124.96302/


124.96290/

Programme selector




132.12805/

USER INTERFACE BOARD



Motor earth

Heating element earth



132.12640/

