

Tub earth


132.24000/

Door safety interlock

5432


Heating elements

Temperature probe




Recirculation pump


Aqua Control




Drain pump




EXTERNAL MOTOR CONTROL BOARD



Motor



Pressure switch




Analogic pressure level



Anti-interference filter




Earth




124.11050/

124.96302/



Prewash valve
Wash valve



Flow sensor



132.24021/

132.24121/

132.24410/

132.12809/

132.24031/

132.12801/

132.24425/

132.24082/

132.12817/

132.12820/


132.12630/

132.12805/


132.12804/

MAIN ELECTRONIC BOARD


EWM3000 -WM-



Laundry Centre Board



USER INTERFACE BOARD



Programme selector

