



NOT INCLUDED
IN THE ASSEMBLY

132 5230 0/

Door safety
interlock
(Traditional version)

EWM 2500

NOT INCLUDED
IN THE ASSEMBLY

132 5235 0/
Door safety
interlock
(traditional)

132 5231 0/
Door safety
interlock
(instantaneous)

Analogic pressure
level

132 5229 2/

Recirculation pump version

132 5236 4/

132 5225 5/
Prewash valve

132 5225 5/
Wash valve

132 5228 0/

132 5233 0/
Flow sensor

Drain pump

132 5226 2/

Heating element

Temperature probe

General earth

132 5240 2/
Anti interference filter

NOT INCLUDED
IN THE ASSEMBLY

132 5222 0/

132 5221 0/

Tub earth

132 5239 0/

Cim motor

132 5237 0/

132 5238 0/

External motor control board