



COMUTATOR CUPTOR  
OVEN SWITCH

POZITIE	0	1	2	3	4	5	6
1	0-1	0-2	0-3	0-4	0-5	0-6	0-7
2	1-2	1-3	1-4	1-5	1-6	1-7	1-8
3	2-3	2-4	2-5	2-6	2-7	2-8	2-9
4	3-4	3-5	3-6	3-7	3-8	3-9	3-0
5	4-5	4-6	4-7	4-8	4-9	4-0	4-1
6	5-6	5-7	5-8	5-9	5-0	5-1	5-2
7	6-7	6-8	6-9	6-0	6-1	6-2	6-3
8	7-8	7-9	7-0	7-1	7-2	7-3	7-4
9	8-9	8-0	8-1	8-2	8-3	8-4	8-5

