


29



342 7507 34

OVEN SWITCH

POS.	0	♀	60-240	270	300	330
4-P2		■	■	■	■	■
3-P1						■
1-P1			■			
2-P1					■	
5-P3		■	■	■	■	■