

OVEN SWITCH

	0	30	60-240	270	300	330
POS.	0	30	60-240	270	300	330
4-P2						
3-P1						
1-P1						
2-P1						
5-P3						

HOB SWITCH
THE SEVEN POSITIONS OF THE SWITCH
ARE EQUIDISTANT DISTRIBUTED

POS	0	6	5	4	3	2	1
4 - P2							
3 - P2							
3 - P1							
1 - P1							
2 - P1							
5 - P3							

29

