

Nota: Os contactos dos microswitches estão no arranjo de porta aberto

J10

10	20	30	40	50	60	70	80	90	100
11	12	13	14	15	16	17	18	19	20

