



J11

20	19	18	17	16	15	14	13	12	11
10	9	8	7	6	5	4	3	2	1

Nota: Os contactos dos microswitches estão na situação de porta aberta.

2008-06-27