


# WIRING DIAGRAM (INDOOR UNIT)



NOTES:  
The Functions In The Rectangle Are Available For Particular Air-condition.