


SW1				
Anti-cold air	Factory setting	Factory setting	Factory setting	Factory setting
TE1	28	30	Fan motor do not stop.	
TE2	30	32		
TE3	24	28		
TE4	15	24		
TE5	32	35		
TE6	30	32		

TYPE_SELECTION	
SW7	TYPE.
	20
	26
	32/35
	53

TEMPERATURE COMPENSATE	
SW6	$\Delta T$
	6
	2
	4 (Factory setting)
	According to the EEPROM setting

SW3		
Auto restart	YES (Factory setting)	NO



SW2		
FAN SPEED	HIGH SPEED (Factory setting)	SUPER HIGH SPEED

## WIRING DIAGRAM INDOOR UNIT

CODE	PART NAME
CN1-20	P.C BOARD SOCKETS
FAN1	INDOOR DC FAN MOTOR
M1	SWING MOTOR
PUMP	PUMP
RT1	ROOM TEMPERATURE
RT2	PIPE TEMPERATURE
XP1-XP6	CONNECTORS
XS1-XS6	CONNECTORS
XT1	5-WAY TERMINAL
FAN2	INDOOR AC FAN MOTOR

NOTE:  
The wiring diagram is for explanation purpose only. The actual shape of the components may be different.