


SCHEMATIC DIAGRAM



SWA: THE PRIMARY INTERLOCK SWITCH
 SWB: THE SECOND INTERLOCK SWITCH
 SWC: THE MONITOR INTERLOCK SWITCH
 L : OVEN LAMP
 FM : FAN MOTOR
 TM : TRAY MOTOR
 FU1 : MAGNETRON THERMOSTAT
 FU2 : OVEN THERMOSTAT
 F1 : MAIN FUSE
 F2 : HIGHT VOLTAGE FUSE

JENS_005 (947602340)