


SCHEMATIC DIAGRAM



(DOOR OPENED, COOK OFF CONDITION)

SW1: TIME CONTROL SWITCH
 SW2: POWER CONTROL SWITCH
 SWA: THE PRIMARY INTERLOCK SWITCH
 SWB: THE SECOND INTERLOCK SWITCH
 SWC: THE MONITOR INTERLOCK SWITCH
 L : OVEN LAMP
 T : TIMER MOTOR
 FM : FAN MOTOR
 TM : TRAY MOTOR
 FU : SAFETY THERMOSTAT
 H : HEATER
 F1 : MAIN FUSE
 F2 : HIGHT VOLTAGE FUSE

D : HIGHT VOLTAGE DIODE
 C : HIGHT VOLTAGE CAPACITOR