


SCHEMATIC DIAGRAM



SW1: LAMP/MOTORS CONTROL SWITCH
 SW2: POWER CONTROL SWITCH
 SWA: THE PRIMARY INTERLOCK SWITCH
 SWB: THE SECOND INTERLOCK SWITCH
 SWC: THE MONITOR INTERLOCK SWITCH
 L : OVEN LAMP
 FM : FAN MOTOR

TM : TRAY MOTOR
 FU1 : MAGNETRON THERMOSTAT
 FU2 : OVEN THERMOSTAT
 F1 : MAIN FUSE
 F2 : HIGHT VOLTAGE FUSE
 D : HIGHT VOLTAGE DIODE
 C : HIGHT VOLTAGE CAPACITOR