


# SCHEMATIC DIAGRAM



SW1: LAMP/MOTORS CONTROL SWITCH  
 SW2: POWER CONTROL SWITCH  
 SW3: GRILL CONTROL SWITCH  
 SWA: THE PRIMARY INTERLOCK SWITCH  
 SWB: THE SECOND INTERLOCK SWITCH  
 SWC: THE MONITOR INTERLOCK SWITCH  
 L : OVEN LAMP  
 FM : FAN MOTOR

TM : TRAY MOTOR  
 FU1 : MAGNETRON THERMOSTAT  
 FU2 : OVEN THERMOSTAT  
 F1 : MAIN FUSE  
 F2 : HIGH VOLTAGE FUSE  
 D : HIGH VOLTAGE DIODE  
 C : HIGH VOLTAGE CAPACITOR  
 H : GRILL

(DOOR OPENED, COOK OFF CONDITION)