



916347FPM Terim

- 1 Grill cut-out microswitch
- 2 Grill pilot lamp
- 3 Turnspit switch
- 4 Oven lamp switch
- 5 Oven lamp
- 6 Upper heating element + Grill
- 7 Turnspit motor
- 8 Earth
- 9 Terminal block