



TERMINALI	POSIZIONI COMMUTATORE						
	0	1	2	3	4	5	6
P1	1	X					X
	2			X	X	X	X
	3		X				
P2	3	X			X	X	X
	4		X	X		X	X
P3	5	X	X	X	X	X	X