


MODEL BC6914001M



A = SWITCH
 B1 = LIGHT KNOB THERMOSTAT
 B2 = LIGHT OVEN
 B3 = LIGHT INDICATOR
 B4 = LIGHT KNOB SWITCH
 L1 = LIGHT OVEN RIGHT
 L2 = LIGHT OVEN LEFT
 Q1 = KLIXON SAFETY
 Q2 = KLIXON COOLING FAN
 P = ELECTRONIC TOUCH CONTROL

RF4 = RING ELEMENT
 RF5 = GRILL ELEMENT
 RF6 = OUTER TOP ELEMENT
 RF7 = BOTTOM ELEMENT
 SP = RELAY CIRCUIT BOARD
 SC = MEAT PROBE
 T1 = THERMOSTAT
 V = OVEN FAN
 VT = COOLING FAN
 X = THERMINAL CONNECTION