



wiring mains terminal
 article number code 387 694 100



view from top



control lines

contact	article number code
induction module left/BC4 - induction module right/BC4	387 729 900
induction module right/BC3 - user interface/XC01 or BC01	387 812 100