



wiring mains terminal  
article number code 387 694 100



view from top



control lines

contact	article number code
induction module left/BC4 - induction module right/BC4	387 729 900
induction module right/BC3 - user interface/BC03	387 202 503
induction module right/BP01 - user interface/BPS02	387 992 300