



wiring mains terminal
 article number code 387 694 100



view from top



control lines

contact

article number code

| | |
|--|-------------|
| induction module left/BC4 - induction module right/BC4 | 387 729 901 |
| induction module right/BC3 - user interface/XC01 | 387 812 101 |
| induction module left/B81 (Dummy NTC) | 387 540 300 |