



wiring mains terminal  
article number code 387 694 100



view from top



control lines

contact

induction module left/BC4 - induction module right/BC4  
induction module right/BC3 - user interface/BC01

article number code

387 729 901  
387 812 102

P0DGT300000081