


PRESOSTATO
PRESSURE SWITCH



LAMPARA PILOTO
PILOT LAMP

TECLA NO CENTRIFUGADO
NO SPIN BUTTON

CONDENSADOR
CAPACITOR

ELECTROVALVULA
COLD WATER INLET VALVE

BOMBA DESCARGA
DRAIN PUMP

INTERRUPTOR PUERTA
DOOR SAFETY INTERLOCK

MOTOR PROGRAMADOR
TIMER MOTOR

RESISTENCIA
HEATING ELEMENTS

MOTOR
MOTOR

PRESOSTATO
PRESSURE SWITCH