


# EWM 2100

Door safety interlock (Traditional version)

NOT INCLUDED IN THE ASSEMBLY


132 5230 0/



NOT INCLUDED IN THE ASSEMBLY

126 6123 00

132 5231 0/




Analogic pressure level

132 5229 0/




Recirculation pump

132 5234 0/



Drain pump




NOT INCLUDED IN THE ASSEMBLY


126 6122 20

132 5222 0/

132 5221 0/



Heating element



132 5226 0/

126 6122 00


- 126 6122 00 Prewash valve
- 126 6122 00 Wash valve
- 126 6122 00 Bleaching valve

132 5232 0/

Flow sensor

132 5233 0/

132 5228 0/




Anti interference filter

132 5220 0/

132 5223 0/

Motor

132 5224 0/



Without 1/2 field

Motor earth

Earth