



	0	90	180	270
4 - P2				
3 - P1				
1 - P1				
2 - P1				
5 - P3				

OVEN SWITCH