



ELECTRIC DIAGRAM

	8			
	0	72	144	216
4 - P2				
3 - P1				
1 - P1				
2 - P1				
5 - P3				

OVEN SWITCH

1