





# A04220501



**OVEN SWITCH 8**

Position	0	72	144	216	288
4 - P2					
3 - P1					
1 - P1					
2 - P1					
5 - P3					