



	2	1	1	1	2	1	2	Quantity of possible plug			
	1	2	3	4	5	6	7	8	9		
	Marking of connectors										
	Front view										
	P1 P2 P3 P4 P5 P6 P7 P8 P9										
	Marking of connectors										
	6			2		1		1		Quantity of possible plug	
POSITIONS (CLOCKWISE ROTATION ANGLE)	0									0°	OFF
	1	x	x	x			x	x	x	45°	
	2	x		x	x	x		x	x	90°	
	3	x	x				x	x	x	135°	
	4	x	x		x			x	x	180°	
	5	x		x	x		x	x	x	225°	
	6	x		x			x	x	x	270°	
	7	x	x	x	x		x	x	x	315°	ECO
	COOKING FUNCTIONS										

ROTARY SWITCH : A12665202