



1	1	1	1	2	1	2	Quantity of possible plugs		
1	2	3	4	5	6	7	8	9	Marking of connectors
Front view									
P1	P2	P3	P4	P5	P6	P7	P8	P9	Marking of connectors
							Quantity of possible plugs		

ROTARY SWITCH : A12665502

POSITIONS (CLOCKWISE ROTATION ANGLES)	Quantity of possible plugs									COOKING FUNCTIONS
	0	1	2	3	4	5	6	7	8	
0°										OFF
36°	x									36°
72°	x	x								72°
108°	x	x	x							ECO
144°	x	x	x	x						144°
180°	x	x	x	x	x					180°
216°	x	x	x	x	x	x				216°
252°	x	x	x	x	x	x	x			252°
288°	x	x	x	x	x	x	x	x		288°
324°	x	x	x	x	x	x	x	x	x	324°