



USER INTERFACE BOARD

Programme selector

Door safety interlock

132 2493 1/

132 1280 6/

124 9331 3/

NOT INCLUDED IN THE ASSEMBLY

MAIN ELECTRONIC BOARD

132 3444 0/

132 3442 0/

132 3442 0/

132 2492 0/

132 3443 0/

132 2465 0/

124 9629 0/

132 2474 0/

NOT INCLUDED IN THE ASSEMBLY

Tub earth