

OPTIONAL: USER INTERFACE BOARD + WIRING (QUELLE INPUT)

NOT INCLUDED IN THE WIRING HARNESS
ONLY IN VERSION WITH LCD

(HIGH) ENV06 DRYER

